Home » Tech » Electrical Items For Custom Builders

K-Four Switches - Electrical I tems For Custom Builders Ready To Wire

By Jerrod Jones photographer: Jerrod Jones

Select Make



When you are doing any custom wiring of accessories like fuel pumps, electric fans, lights, etc., you need to make sure that you have good, quality components, and that you know the basics of wiring so you don't have to go back to redo installations or, worse yet, have your ride burn down due to electrical issues. We stopped by K-Four Switches to talk to the master of maximum voltage, Richard Hopper. Richard is a self-taught electrical engineer who supplies shops like McKenzie's, Kartek, Off-Road Warehouse, and Pacific Warehouse with

electrical components to fit all sorts of off-road toys. K-Four's specialty is triple-sealed switches that will live for many times longer than conventional-sealed switches when put in the dirtiest and dustiest of conditions (like on the dash of your sandrail).

Richard walked us through the basics of what our wiring choices were and a few of the components that you can use to make electrical systems topnotch.

Wire	Gauge	Size	Maximum	Amperage

18	16A
16	22A
14	30A
12	40A
10	50A
8	70A



Here is the same highquality switch unsealed (left) and sealed (right). K-Four triple seals all of its switches in-house, with a flexible acrylic coating on the body, Oring seal, and a toggle switch boot cover. This ensures that all moisture and dirt are kept out of the contacts.



Switch guards can be ordered in five different colors and can be color-coordinated to what reminds you of what application the switch turns on. We always like a red one for nitrous and a blue one for an electric fan override.



This is one of the displays that K-Four builds for shops that carry K-Four products. It shows the variety of switches and lights you can use to build yourself a custom dash and/or electrical system.

Related Photos







Selec

Get free and easy new ca



MORE PHOTOS

Related Articles

Championship Off Road Racing 2008 Pomona -

These 2wd terrors dominate the track and everything el: their way!... more

Nitto Dura Grapplers

Highway Terrains... more

Championship Off Road Racing Round 13 & 14 Desert Race Trucks

Full Size 2 Wheel Drive Trucks... more

Championship Off Road Racing Round 13 and Pro4 Desert Race Trucks

Full Size 4 Wheel Drive Trucks... more



new to offroad

I have a 2005 ford f150 fx4 supercab 4x4. I mostly go to where there is a little mud and... more

Who makes the Best mid size truck?

Not that many people even care, (I for one sure don't) ${\tt k}$ IFS crap out there, who... ${\tt more}$



K-Four highly recommends circuit breakers instead of fuses. Obviously fuses will always have their place and are better suited for some applications. But fuses do not reset and need to be replaced when they blow. There are two types of circuit breakers automatic and manually switched. They can be ordered to trip at different amperages, depending on your application, and should be made to trip at approximately 80 percent of the switch's maximum load capacity.



This is expanding wire loom that can be ordered in 1/8-, 1/4-, 3/8-, or 1/2-inch sizes. It expands (like a Chinese finger trap) so you can stretch 1/2-inch tubing to fit 3/4-inch worth of wires. It's a good idea to put heat shrink on the end of the loom to prevent fraying and for general cleanliness.



Battery disconnects are popular as not only theft deterrent and to limit battery drain, they are also crucial to motorsports. The ability to immediately cut all power coming from the battery can be very handy and sometimes crucial during emergency situations. Left to right, a heavy-duty disconnect with a 180-amp continuous rating, a lightweight plastic-body disconnect (50-amp continuous), and a keyedbattery disconnect for theft prevention purposes.



Discussion related to the Nissan Frontier and derivatives

Check it out... we have almost 800 photos from the race

Project 4x4Link 99 Ford Ranger

Nissan Frontier Discussion

and Sunday. Check it out!... more

CORR Rounds 1 & 2 Coverage is up!

Pathfinder, etc.)... more

So I picked up a few more sticks of 1 3/4" .120 DOM ste today to continue on with... more

Championship Off Road Racing Pomona Round Well the first two rounds of the 2008 CORR season are r books. This first weekend of... more

Project 4x4 Link 99 Ford Ranger Shocks

We dig into the Sway-A-Way shocks that dampen 4x4Lir more

4x4Link 99 Ranger 4x4 Cage Part 2

We make more progress on 4x4Link's Passanger Protect (that's fancy for Roll Cage). ... more



To cleanly hold your wires up out of the way while running them along a framerail or sidewall, cushion clamps are your best bet. They have rubberized isolators that keep the metal of the clamp from rubbing through wires' insulation.



From left to right are five of the most popular switch options being ordered: a nonsealed toggle, a triple-sealed toggle, a toggle with a switch guard, an incandescent triple-sealed toggle, and a rubberbooted triple-sealed toggle switch. You can order switches that handle up to 30 amps from K-Four. If the switch you have installed in your electrical system is getting hot, then it is overloading and you'll need to replace it with a higher amperage switch.



Discuss in Our Forums

Bookmark & Share This Article: